

STEP 1

 Franmar

TIP SHEET

COLOR CHANGE™

ON PRESS INK REMOVER

Safe and Simple Ink Color Changes

Made with Soybeans • 100% Biodegradable • Non-Toxic and Non-Caustic

Quickly change colors on press or open clogged mesh areas during a run, saving valuable time and money. **Franmar's On Press Ink Remover** is non-aerosol and replaces harsh chemicals such as Methylene Chloride without the negative side-effects and offensive odor.

Color Changing Directions

- 1 Spray or pour a small amount onto screen.
- 2 Wipe screen clean with shop towel(s).
- 3 Repeat on back of screen image.
- 4 Wipe both sides of screen with degreaser or damp shop towel.
- 5 Allow screen to dry thoroughly.

Note: If tape does not stick, wipe again with damp shop towel and allow to dry.

Screen Opener Directions

- 1 Spray or pour a small amount onto shop towel.
- 2 Wipe screen image area clean.

Usage Tips

- Remember, less is better. Use a small amount and you will immediately see the ink loosen.
- Works great for cleaning ink smudges on back of screen.
- **Franmar's Screen Degreaser** can be used to wipe away any solvent residues.
- Start with lighter inks and move up to darker inks when printing.

Chat with a live customer service rep (No phone menu maze!)

800-538-5069

7am - 5:30pm Mon - Thurs. Friday 7am - 5:00pm CT

or visit our website: www.franmar.com

 Franmar®

rev. 6/15/2015