



TIP SHEET

SCORCH•E•DOO™

SCORCH REMOVER

Saves 100% White Cotton Apparel

Made with Soybeans • 100% Biodegradable • Non-Toxic and Non-Caustic

Scorch marks left by flash curing units and dryers have always been an occasional problem for screen printers. **Franmar's Scorch Remover** is a great product to have on hand for those moments shirts get scorched with no extra's in sight. An environmentally safe choice to recover burned white cotton shirts.

Directions

- 1 Spray affected area until damp.
- 2 Place in dryer at reduced heat or higher belt speed multiple times until dry. A warm iron or heat press may also be used.
- 3 Repeat process if necessary.

Usage Tips

- Use only on light scorching. Will not work on medium to severe scorching.
- Use only on white cotton apparel. Will not work on polyester blends.
- A heat press at a low heat (250°F - 300°F) works well in applying Scorch Remover.

Chat with a live customer service rep (No phone menu maze!)

800-538-5069

7am - 5:30pm Mon - Thurs. Friday 7am - 5:00pm CT

or visit our website: www.franmar.com



rev. 6/15/2015